

# product information sheet

Trade Mark	AEG
Model	NDC7721SB 942051553
Annual Energy Consumption (kWh/year)	50.2
Energy Efficiency class	A
Fluid Dynamic Efficiency	33.7
Fluid Dynamic Efficiency class	A
Lighting Efficiency (lux/W)	30.2
Lighting Efficiency class	A
Grease Filtering Efficiency	65.1
Grease Filtering Efficiency class	D
Air flow at minimum and maximum speed in normal use (m <sup>3</sup> /h)	340/630
Air flow at intensive or boost setting (m <sup>3</sup> /h)	730
Airborne acoustical A-weighted sound power emissions at minimum and maximum speed in normal use (dB(A))	51/64
Airborne acoustical A-weighted sound power emissions at intensive or boost setting (dB(A))	67
Power consumption in standby mode (W)	1
Power consumption in off mode (W)	1

## Product information according to Commission regulation (EU) No 66/2014

Attribute Name	Symbol	Value	Unit
Model Denomination		NDC7721SB 942051553	
Annual Energy Consumption	AEC <sub>hood</sub>	50.2	kwh/a
Time increase factor	f	0.8	
Fluid Dynamic Efficiency	FDE <sub>hood</sub>	33.7	
Energy Efficiency Index	EEL <sub>hood</sub>	49.6	
Measured air flow rate at best efficiency point	QBEP	384.5	m <sup>3</sup> /h
Measured air pressure at best efficiency point	PBEP	460	Pa
Maximum air flow	Q <sub>max</sub>	730.0	m <sup>3</sup> /h
Measured electric power input at best efficiency point	WBEP	145.8	W
Nominal power of the lighting system	WL	10.5	W
Average illumination of the lighting system on the cooking surface	E <sub>middle</sub>	317	lux
Measured power consumption in standby mode	P <sub>s</sub>	1	W
Measured power consumption off mode	P <sub>o</sub>	1	W
Sound power level	LWA	64	dB

**EN 61591 - Household range hoods and other cooking fume extractors – Methods for measuring performance**

**EN 60704-2-13 - Household and similar electrical appliances – Test code for the determination of airborne acoustical noise – Part 2-13: Particular requirements for range hoods**

**EN 50564 - Electrical and electronic household and office equipment. Measurement of low power consumption**

**Suggestions for a correct use in order to reduce the environmental impact:**

- Switch ON the hood at minimum speed when you start cooking and kept it running for few minutes after cooking is finished.
- Increase the speed only in case of large amount of smoke and vapour and use boost speed(s) only in extreme situations.
- Replace the charcoal filter(s) when necessary to maintain a good odour reduction efficiency.
- Clean the grease filter(s) when necessary to maintain a good grease filter efficiency.
- Use the maximum diameter of the ducting system indicated in this manual to optimize efficiency and minimize noise.